



Using the Vacuum Cleaner

1. Do not use the cleaner to vacuum dry waste.
2. Dry hands, switch off and unplug before emptying the waste container.
3. Empty the waste container before it is full.
4. If you think the cable may be cut or damaged in any way, switch off and unplug at the mains before inspecting it, if the cable attached to the vacuum cleaner is damaged, stop using the equipment. Contact the hire company. If an extension cable has been damaged, do not use it again.

Keep this leaflet safe as it may be required for reference at a future date

Vacuum Cleaner - WET

The rules and procedures in force where people are at work may require the person responsible for this equipment to carry out a specific risk assessment.

It is important to read all of this leaflet BEFORE you use the Vacuum Cleaner



1. Electricity is dangerous and must always be used with great care.
2. Water and electricity make a dangerous combination. Keep water away from the electrical parts.
3. This vacuum cleaner is designed for vacuum collection of water and wet waste material.
4. The action of this vacuum cleaner can cause injury or damage if the equipment is not used in a careful and controlled way.
5. Familiarise yourself with how the equipment works before starting work.
6. Plan and think ahead to make sure you will always be working safely.
7. You should have at least the following items of protective equipment: rcd if using a 230 volt (mains) supply.
8. This equipment must not be used by minors, or by anyone under the influence of drugs or alcohol.
9. This vacuum cleaner is designed for operation by an able bodied adult. Anyone with either temporary or permanent disability must seek expert advice before using it.



Every effort has been made by HAE/EHA to ensure that the information given in this document and supporting material is accurate and not misleading. HAE/EHA cannot accept responsibility for any loss or liability perceived to have arisen from the use of any such document/material. Only Acts of Parliament and Statutory Instruments have the force of law and only the courts can authoritatively interpret the law.



Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
website: www.hae.org.uk

v:112016

©Copyright Hire Association Europe April 2011

Any unauthorised reproduction – manually or electronically – is STRICTLY prohibited

Telephone: 44 (0) 121 380 4600
Fax: 44 (0) 121 333 4109
Email: mail@hae.org.uk
www: www.hae.org.uk

Hire Association Europe
2450 Regents Court
The Crescent
Birmingham Business Park
Solithull B37 7YE



1. Use a residual current device ("rcd") plugged directly into the 230volt socket. Plug your equipment into the rcd. This will help to protect you against electric shock if the cable or equipment gets damaged.
2. Use the "TEST" button to check that the rcd is working each time you use it. Reset the rcd according to the instructions supplied with it.
3. If you need extension cables, follow any special instructions given by the hire company. If the instructions do not give any special instructions, you should only use a suitable rated heavy duty one, not longer than 50 metres (160 feet). Put it directly into the rcd. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.
4. Lay it out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.
5. Make sure that any extension cable connections are dry and safe.



1. If you are using a portable transformer, plug the transformer directly into the 230 volt socket. Do not use any 230v extension cables.
2. If you need to use an extension cable, follow any special instructions given by the hire company. If the instructions do not give any special instructions, you should only use a suitable rated heavy duty 110v extension cable, not longer than 50 metres (160 feet). You must only use an extension cable between the transformer and the equipment.
3. Lay the extension cable out carefully avoiding liquids, sharp edges, doorways or windows where it might be trapped, and places where vehicles might run over it. Unroll it fully or it will overheat and could catch fire.



230 VOLT EQUIPMENT (SQUARE PIN OR BLUE PLUG)

4. Make sure that any extension cable connections are dry and safe.



Before Starting Work...

1. Check your equipment, cables, plugs and all equipment. If anything is found damaged, do not use the vacuum cleaner- contact the hire company.
 2. Check that the plug on your equipment matches your supply. Do not try to force connections or improvise them.
 3. Equipment with a cylindrical yellow industrial plug fitted is designed to run off a special 110v supply. The portable transformer if you need a vacuum cleaner on, you must know how to stop it.
 4. This machine is not suitable for work involving asbestos or other hazardous materials.
 5. Do not use it for vacuuming flammable, corrosive or toxic wastes such as petrol, or weed killer.
 6. Do not try to clean up waste oil or sludge, it will clog up the machine and may damage it.
 7. Empty the waste container before it is full.
 8. If the ball valve will shut off the air passage causing the machine to overheat rapidly.
 9. Check on how the on/off switch operates. Before you switch the vacuum cleaner on, you must know how to stop it.
- ELECTRICAL SAFETY**
- Your equipment will only operate on one voltage: it will be 110v or 230v. 110v equipment will have a yellow industrial plug fitted. 230v equipment will have either a normal

VACUUM CLEANER

WORK AREA

1. Do not use this vacuum cleaner where there is a danger of explosion. It will ignite fumes from petrol, or gas cylinders.
2. Make sure that the area is clear and safe and that no-one is near to you or could distract you. Keep children and animals well clear.
3. Do not use this cleaner in the rain or where the electrical parts might get wet.